

# SOS Diagnostics

## SKREEM Immobilizer Module Removal

### 2002-2006

The SKREEM module is located behind the instrument cluster. To access it, remove the ½ round cover over the instrument cluster. Use a #20 Torx driver to remove the 2 screw located in front of and above the cluster. These screws are pointing up.

After removing the 2 screws the trim piece that surrounds the cluster and has an air vent on either side will pop off. Pull it towards the rear of the van.





On the pictures above you will see the trim pulled loose. This is as far as you need to go. You do not need to completely remove it or disconnect the wires to the optional switches. This will expose 2 more #20 Torx screws on either side of the dash cover over the top of the cluster. After removing them, remove the cover.

Now you will see a green wiring connector on a small black box on the back of the cluster. This black box with a white label made by Temic is the SKREEM. I usually remove the SKREEM without removing the instrument cluster by just unhooking it from the back of the cluster. Usually there are no screws, only plastic clips. If you want to remove the cluster to see it better, remove the 2 screws visible on top of the cluster.



This is the SKREEM module mounted to the back of the instrument cluster.



With the key off, disconnect the green connector and remove the SKREEM.